

T-SERV II and T-SMART CSU Plug-in Installation

Basic Steps

1. Align the card's edge with the top and the bottom card guides in the 12-slot shelf, or the left and the right card guides in the 4-slot shelf.
2. Lift the front-panel latch and press the card into the slot until the card's rear-panel connectors snap into place.
3. Press down on the front-level latch to securely seat the card in the shelf. When the card is installed correctly, there is no gap between the card's front panel and the shelf.

T-SERV II

When you install a plug-in T-SERV CSU, the PWR LED indicates the results:

- If green, the installation was successful and you can connect the T-1 cable to the shelf.
- If off, the installation was unsuccessful. Refer to the Plug-in CSU manual included with the shelf for troubleshooting information.

T-SMART

A 20-second self-test runs when you install a plug-in T-SMART CSU into a powered shelf. The PWR/FAIL LED indicates the results:

- If green, the self-test was successful and you can connect the T-1 cable to the shelf.
- If red, the self-test failed. Refer to the Plug-in CSU manual included with the shelf for troubleshooting information.

T-SMART plug-ins may require further configuration. Log on via the Group Controller Unit (GCU) or the Shelf Interface Unit (SIU) and refer to the documentation provided with those units for information on configuring the plug-in.

Additional Information

Please refer to the manuals that were included with the shelf or visit www.kentrox.com/library for downloadable PDF versions of the manuals.



Copyright © 2005 by Kentrox, LLC. All rights reserved
650-00527-00